CORRECTLY FITTED AND MAINTAINED FIRE DOORS

FIRE DOOR

FIRE

DOOR

FIRE DOOR



Don't take the risk, check your fire doors today with this easy to follow gap checker guide.

- 1. Place your £1 coin in the gap around your door to the frame.
- 2. Your £1 Coin should fit nice & tight in the gap without being too loose, you want a 3mm gap + or - 1mm, 4mm Maximum & 2mm Minimum.
- 3. If your £1 coin will not fit into the gap at all or is too loose, contact Fire Doors Rite, as this may hinder the fire door working correctly with the Intumescent Fire or Smoke Seals in the event of a Fire.
- 4. To check the floor to door gap, place 3 x £1 coins together. If Your 3 x £1 coins placed together fit under the door tightly, the floor to door gap is okay, if not you will be at risk of smoke inhalation at a faster rate in the event of a fire, a gap of 10mm (3x £1 Coins) or less is acceptable.





2

Tel: 0203 6333 568 Email: info@firedoorsrite.co.uk www.firedoorsrite.co.uk